

Front shock absorber disassembly detail diagram

PHOTO	NO.	Part CODE	Chinese/English name and specification	UNIT	QTY	NOTE
	1.1	371400-T500-00001	前减震器-右(低座版) Front Shock Absorber - Right (Low Seat version)	PIECE	1	regular version with a high seat and low seat 2 states, the factory version only used the high seat, if the parts do not add the state, regular and factory can be used
	1.2	371400-T501-00001	前减震器-右(高座版) Front Shock Absorber - Right (High Seat version)	PIECE	1	
	2.1	371300-T500-00001	前减震器-左(低座版) Front Shock Absorber - Right (Low Seat version)	PIECE	1	
	2.2	371300-T501-00001	前减震器-左(高座版) Front Shock Absorber - Right (High Seat version)	PIECE	1	
	3	371306-T501-00000	复原调节座 Recovery adjustment base	PIECE	1	
	4	371307-T501-00000	复原调节座密封圈 $\phi 25 \times \phi 29.5 \times 1$ Recovery of adjusting base seals $\phi 25 \times \phi 29.5 \times 1$	PIECE	1	
	5	5104-022418-000	O型圈 $\phi 22.4 \times 1.8$ O-ring $\phi 22.4 \times 1.8$	PIECE	1	
	6	371308-T501-00000	复原调节器 Recovery regulator	PIECE	1	
	7	5104-003118-000	O型圈 $\phi 3.15 \times 1.8$ O-ring $\phi 3.15 \times 1.8$	PIECE	1	
	8	5030-00350-BS00	钢珠 $\phi 3.5$ The steel ball $\phi 3.5$	PIECE	1	
	9	5012-03006-BS00	压缩弹簧 $\phi 0.5 \times \phi 3.3 \times 6-5$ compression spring	PIECE	1	
	10	5104-006015-000	O型圈 $\phi 6 \times 1.5$ O-ring $\phi 6 \times 1.5$	PIECE	1	
	11	5020-06406-SC00	挡圈 $\phi 6.4 \times \phi 0.6$ Retaining ring $\phi 6.4 \times \phi 0.6$	PIECE	1	
	12	371305-T501-00000	前减左底筒 Front shock absorber left bottom cylinder	PIECE	1	
	13	371405-T501-00000	前减右底筒 Front shock absorber right bottom cylinder	PIECE	1	
	14	371309-T501-00000	前叉管密封座 Front fork tube seal base	PIECE	1	
	15	5104-032831-000	O型圈 $\phi 32.8 \times 3.1$ O-ring $\phi 32.8 \times 3.1$	PIECE	1	
	16	5104-040026-000	O型圈 $\phi 40 \times 2.65$ O-ring $\phi 40 \times 2.65$	PIECE	1	
17	5018-32520-BS00	平垫 $\phi 32.5 \times \phi 44 \times 2$ washer $\phi 32.5 \times \phi 44 \times 2$	PIECE	1		
18	5020-33212-BS00	挡圈 $\phi 33.2 \times \phi 1.2$ Ring $\phi 33.2 \times \phi 1.2$	PIECE	1		

Front shock absorber disassembly detail diagram-1

PHOTO	NO.	Part CODE	Chinese/English name and specification		UNIT	QTY
	19	371310-T501-00000	前叉管	Front fork tube	PIECE	1
	20.1	371311-T501-00000	前减震外筒578mm(高座版)	Front shock absorbing Sleeve 578mm(high seat version)	PIECE	1
	20.2	371311-T500-00000	前减震外筒570mm(低座版)	Front shock absorbing Sleeve 570mm low seat version)	PIECE	1
	21	5020-67628-BS00	挡圈 $\phi 67.6 \times \phi 2.8$	Ring $\phi 67.6 \times \phi 2.8$	PIECE	1
	22	910021-T501-00000	DU衬套 $\phi 48 \times \phi 50 \times 20$	DU bushing $\phi 48 \times \phi 50 \times 20$	PIECE	1
	23	910021-T501-00001	DU衬套 $\phi 49 \times \phi 52 \times 15$	DU bushing $\phi 49 \times \phi 52 \times 15$	PIECE	1
	24	5018-50020-BS00	平垫 $\phi 50 \times \phi 60 \times 2$	washer $\phi 50 \times \phi 60 \times 2$	PIECE	1
	25	371301-T501-00000	前减震油封 $\phi 49 \times \phi 60 \times 10$	Front shock absorber damping oil seal $\phi 49 \times \phi 60 \times 10$	PIECE	1
	26	5020-65018-BS00	挡圈 $\phi 65 \times \phi 1.8$	Ring $\phi 65 \times \phi 1.8$	PIECE	1
	27	371302-T501-00000	前减震防尘封 $\phi 47.3 \times \phi 64 \times 11$	Front shock absorber dust seal $\phi 47.3 \times \phi 64 \times 11$	PIECE	1
	28	5018-29035-BS00	平垫 $\phi 29 \times \phi 34 \times 3.5$	washer $\phi 29 \times \phi 34 \times 3.5$	PIECE	1
	29	5018-29415-BS00	平垫 $\phi 29.4 \times \phi 34 \times 1.5$	washer $\phi 29.4 \times \phi 34 \times 1.5$	PIECE	1
	30	371312-T501-00000	前减弹簧衬套座	Front shock spring bushing base	PIECE	1
	31	910021-T501-00002	DU衬套 $\phi 43.5 \times \phi 45.5 \times 8$	DU bushing $\phi 43.5 \times \phi 45.5 \times 8$	PIECE	1
	32	371313-T501-00000	前减弹簧衬套座固定套	Front shock spring bushing base fixing ring	PIECE	1
	33.1	5012-05045-BS00	减震弹簧 $\phi 5.3 \times \phi 45 \times 475 - 24.5$ (高座版)	shock spring $\phi 5.3 \times \phi 45 \times 475 - 24.5$ (high seat version)	PIECE	1
	33.2	5012-05045-BS01	减震弹簧 $\phi 5.3 \times \phi 45 \times 434 - 24.5$ (低座版)	shock Spring $\phi 5.3 \times \phi 45 \times 434 - 24.5$ (low seat version)	PIECE	1
	34	371314-T501-00000	前减压缩阀组合	Front shock compression valve assembly	PIECE	1
	35	371315-T501-00000	前减高压缸	Front shock absorbing high pressure cylinder	PIECE	1
	36	371316-T501-00000	前减油缸锁紧套M29*1*28	Front shock cylinder locking washer M29*1*28	PIECE	1

Front shock absorber disassembly detail diagram-2

PHOTO	NO.	Part CODE	Chinese/English name and specification	UNIT	QTY
	37	371317-T501-00000	前减工作缸 Front shock absorber work cylinder	PIECE	1
	38	371318-T501-00000	前减导向座组合 Front shock guide base assembly	PIECE	1
	39.1	371319-T501-00000	前减连杆组合(高座版) Front damping connecting rod combination (high seat version)	PIECE	1
	39.2	371319-T500-00000	前减连杆组合(低座版) Front damping connecting rod combination (low seat version)	PIECE	1
	40	5010-13070-BS00	锁紧螺母M13.5*1*7 Lock nut M13.5*1*7	PIECE	1
	41				
	42				
	43				
	44				
	45				
	46				
	47				
	48				
	49				
	50				
51					
52					
53					
54					
55					

### Rear shock absorber disassembly detail diagram

PHOTO	NO.	Part CODE	Chinese/English name and specification	UNIT	QTY
	1.1	371500-T500-00001	后减震器(低座版) Rear shock absorber (low seat version)	PIECE	1
	1.2	371500-T501-00001	后减震器(高座版) Rear shock absorber (high seat version)	PIECE	1
	2	371501-T501-00000	后减阻尼器 Rear Shock Damper	PIECE	1
	3.1	5012-11090-BS00	减震弹簧 $\phi 11.3 \times \phi 90.3 \times 238-7$ (高座版) Rear shock Absorbing Spring $\phi 11.3 \times \phi 90.3 \times 238-7$ (High seat version)	PIECE	1
	3.2	5012-11090-BS01	减震弹簧 $\phi 11.3 \times \phi 90.3 \times 230-7$ (低座版) Shock Absorbing Spring $\phi 11.3 \times \phi 90.3 \times 230-7$ (Low seat version)	PIECE	1
	4	371502-T501-00000	后减弹簧座 $\phi 88 \times \phi 63 \times 6$ Rear Shock Absorbing spring base $\phi 88 \times \phi 63 \times 6$	PIECE	1
	5	5020-62020-LB00	挡圈 $\phi 62 \times \phi 2$ Ring $\phi 62 \times \phi 2$	PIECE	1
	6	371503-T501-00000	后减气囊组合 Rear shock absorber airbag combination	PIECE	1
	7	5014-06012-HX00	内六角沉头螺钉M6*12 Screw,Inner Hex,Countersunk Head	PIECE	1
	8	5104-005515-000	O型圈 $\phi 5.5 \times \phi 1.5$ O-ring $\phi 5.5 \times \phi 1.5$	PIECE	1
	9	5103-172603-002	油封 $\phi 17 \times \phi 26 \times 3$ Oil seal $\phi 17 \times \phi 26 \times 3$	PIECE	1
	10	5107-102621-BS0	关节轴承组合 $10 \times 26 \times 21.8$ Joint bearing combination $10 \times 26 \times 21.8$	PIECE	1
	11	5103-172403-000	油封 $\phi 17 \times \phi 24 \times 3$ Oil seal $\phi 17 \times \phi 24 \times 3$	PIECE	1
	12	371504-T501-00000	后减压压缩调节组合(高座版) Rear shock absorber compression adjustment combination (high seat)	PIECE	1
	13	371505-T501-00000	后减油缸 Rear shock absorber oil cylinder	PIECE	1
	14	5010-60060-BS00	弹簧锁紧螺母M60*1.5*6 Spring lock nut M60*1.5*6	PIECE	1
	15	5010-60130-BS00	弹簧调节螺母M60*1.5*13 Spring adjustment nut M60*1.5*13	PIECE	1
16.1	371506-T501-00000	后减活塞杆组合(高座版) Rear shock piston-rod connection (high seat version)	PIECE	1	
16.2	371506-T500-00000	后减活塞杆组合(低座版) Rear shock piston-rod connection (low seat version)	PIECE	1	
17.1	371512-T501-00000	活塞杆 $\phi 16 \times 256$ (高座版) Piston stem $\phi 16 \times 256$ (high seat version)	PIECE	1	

Rear shock absorber disassembly detail diagram-1

PHOTO	NO.	Part CODE	Chinese/English name and specification		UNIT	QTY
	17.2	371512-T500-00000	活塞杆 φ 16*241(低座版)	Piston stem φ 16*241(low seat version)	PIECE	1
	18	371507-T501-00000	后减连杆导向座	Rear shock rod guide base	PIECE	1
	19	5020-55020-LB00	挡圈 φ 55*2	Ring φ 55*2	PIECE	1
	20	5010-16120-BS00	并紧螺母M16*1.5*12	nut M16*1.5*12	PIECE	1
	21	371508-T501-00000	后减油缸端盖	Rear shock absorber cylinder end cap	PIECE	1
	22	371509-T501-00000	后减减震垫	Rear shock absorber cushion	PIECE	1
	23	371510-T501-00000	后减减震垫罩	Rear shock absorber cushion cover	PIECE	1
	24	371511-T501-00000	后减下托架组合	Rear shock absorber lower bracket combination	PIECE	1
	25					
	26					
	27					
	28					
	29					
	30					
	31					
	32					
	33					
	34					
	35					
	36					